

Table base assembly instructions




STEP ONE

Place the threaded rod through the spider as per diagram. It is essential for base stability that this step and step two are undertaken before any other element of base assembly.




STEP TWO

Tighten nuts either side of the spider. Make sure that the threaded rod does not protrude past the level of the flat surface on the spider, as this will prevent the table top from sitting level on the base after base assembly has been completed.



STEP THREE

Place the column over the threaded bar onto the spider. The threaded rod should now be protruding over the top of the column in its current position.



STEP FOUR

Place base plate over the column and threaded rod, place washer if applicable, and finally place and tighten nut to complete assembly.

Only once these steps have been undertaken in order should a top be fitted.
